

UV-T-RH COMBINED ENVIRONMENTAL TESTING

JET PROPULSION LABORATORY

C. C. Gonzalez

Objectives

- To determine the combined effects of controlled amounts of UV radiation, heat and humidity upon the mechanical properties of module cover materials and the electrical properties of a-Si cells
- To develop the relationships required to relate experimental results obtained in accelerated and controlled-environment tests to field observations

Approach

- Use controlled environment for given period of time
 - Initial calibration of oven with lower-limit environments
 - 85 deg C, 10% RH, 1-2 suns UV
 - Use of increased levels for subsequent tests
- Monitor changes in selected key chemical and physical properties that are expected to control long-term performance
- Correlate controlled-environment test results with outdoor exposure


PRECEDING PAGE BLANK NOT FILMED

Description of Test Equipment

- Environmental chamber
 - Air-interchange, heat-and-refrigeration unit (-40 deg C to 175 deg C)
 - Varying humidity (10-100% (up to 90 deg C))
- UV lamp system:
 - 2000 W UV (1-2 suns)
 - Water cooled
 - Dry-nitrogen purge

Ultraviolet Radiation Source

- Manufacturer: Canrad-Hanovia
- Type: Medium pressure mercury vapor lamp
- Lamp power consumption: 2100 W
- Lamp power output prior to filtering by cooling jacket: 1100 W



Environmental Parameter Measurements

- UV lamp
 - Integrated measurements
 - Actinometers
 - Radiometer
 - Spectral-radiometric measurements
 - Monochrometer
 - Lamp output vs time (qualitative)
- Oven temperature (continuous)
- Relative humidity (periodic)
- Selected sample temperatures

Sample Types


- Module encapsulant & cover materials
 - Material types
 - Tedlar
 - Varying amounts of additives
 - Clear and opaque
 - EVA
 - Size and configuration
 - 3/4" x 4" bare strips
 - 4" x 4" laminated tedlar-EVA-glass coupons
 - 4" x 4" submodules with tedlar front cover
- Amorphous-silicon 4" x 4" submodules

RELIABILITY PHYSICS

Material Parameters Measured (Cover and Encapsulation Materials)


- **Weight loss**
 - Monitor loss of additives and volatiles
 - Correlate with shrinkage
- **Changes in absorbance/transmission**
 - Related to loss of absorbers and to chemical degradation (loss of transmission at 400nm related to yellowing)
- **Tensile Modulus**
 - May not establish rate and trend of photothermal degradation in early stages
- **Visual inspection**
 - Determine pliability of material by depressing laminated material

Tedlar: Percent Weight Loss Versus Time




RELIABILITY PHYSICS


Tedlar (Dry Oven): Percent Weight Loss Versus Time




Tedlar (Vacuum Oven): Percent Weight Loss Versus Time



Module Front Cover Material: Percent Transmission Versus Exposure Time



Changes in I-V Curves of Amorphous Silicon Cells Versus Oven Exposure



Test Results Summary

- **Cover materials**
 - **Weight loss**
 - $\leq 1.35\%$ after 7-weeks exposure
 - **Changes in absorbance/transmission**
 - Results ranged from no change to about 15% gain after 5 weeks
 - **Mechanical properties**
 - Visual observations reveal no significant changes except for one case
- **Amorphous-silicon cells**
 - **IV-curve changes**
 - Average max-power loss of 10-15% after 3-5 weeks exposure

Future Work

- **Refine existing test and sample measurement procedures**
(Develop new ones, if required)
- **Use high-humidity environment and increased temperature levels**
- **Vary UV levels by adding/removing screens and changing sample distance to lamp**
- **Perform parallel sample exposures in dry-heat and vacuum ovens**